



## Quick Start Guide

**1** Download the FilesThruTheAir app and create a user account.



Create an Account




**2** Power your Wireless Alert-PRO using the cable provided and any suitable USB power adapter (optional accessory PSU-5VDC-USB-INTL-WHT).




**3** Configure and connect your Wireless Alert-PRO

Login to the FilesThruTheAir app, select the + icon and follow the step-by-step instructions to set alarm levels, notification preferences, and connect to a Wi-Fi network.

Login



Add device



# 4

## Install your Wireless Alert-PRO in its place of operation

Install the bracket using the two screws provided (wall plugs may be required)

For safety, we recommend mounting this product no more than 2m (6'6") above floor level.

Note: A protective film may be fitted to our humidity sensors. Please remove it before use.

### Product Overview



LED Indication	Meaning
Green Flash  Red Flash  Green Flash  (on Button Press)	Device is in Factory Default Mode
Green Flash Every Ten Seconds (or on Button Press)  10s	Device is Operating and Within Alert Limits
Red Flash Every Ten Seconds (or on Button Press)  10s	Device is Operating and in Alert
Amber Flash Every Ten Seconds (or on Button Press)  10s	Device has Identified a Fault/Warning or Loss of Connection
Green Flash Repeating	Device is in Setup Mode
Long Green Flash	Setup was Successful
Long Red Flash	Setup Failed
Red Flash  Green Flash  Red Flash	Factory Reset Complete (after Ten-Second Button Hold)
Button Press	Function
Quick Press	Status Check (Refer to LED Indicator Table for Status Reference)
Three-Second Hold	Enter Setup Mode
Ten-Second Hold	Factory Reset

## Safety Information

Hereby, Corintech Ltd. declares that the radio equipment type Wireless Alert-PRO is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at [www.filesthrutheair.com/support](http://www.filesthrutheair.com/support). Frequency Range: 2400-2483.5 MHz Power: +19.5 dBm

### Repairing or Modifying

Never attempt to repair or modify Corintech Ltd products. Dismantling them, other than for the purpose of changing replaceable batteries, may cause damage that is not covered under the warranty. Wireless Alert-PRO products do not contain any replaceable batteries or user serviceable parts. Servicing should only be provided by an authorised supplier.

### Disposal and Recycling Information

You must dispose of Corintech Ltd products in accordance with relevant laws and regulations. They contain electronic components and therefore must be disposed of separately from household waste.



Having Trouble?  
see our  
FAQs



## Tech Support

Email: [support@filesthrutheair.com](mailto:support@filesthrutheair.com)  
Telephone: +44 (0) 1425 651111  
[www.filesthrutheair.com](http://www.filesthrutheair.com)

Designed in the UK  
Manufactured in China